


Assemble Instructions Click Rail




STEP 1 : Assemble fastening clips

- First of all determine the place where the Click Rail will be mounted.
- In case of uneven ceilings, leave a space of ± 5 mm between the clips and the ceiling. This simplifies drilling the clips and furthermore prevents a crooked assembly of the Click Rail due to unevenness on the ceiling.
- Mark off the drilling holes for the fastening clips.
- Mount a fastening clip every 40cm by means of screws and plugs.
- Also mount a fastening clip on the dividing line of the rails if you want to connect several lengths of rail. (The clips are also rail connectors).



STEP 2 : Place rail onto clips

- Click the rail (starting from the top side if the space between the clips and the ceiling allows this) onto the mounted clips.



STEP 3 : Place end caps and corner connectors

- Place (if desired) the end caps into the ends of the rail for a neat finish.
- Place (if desired) the corner connectors into the rail for a connection of lengths in inside as well as outside corners.

STEP 4 : Hanging systems

- Finally place the desired hanging systems (which are suitable for the Click Rail) into the rail.

TIP : For the assemble of the Click Rail to a normal wall (concrete/stone) standard plugs of 6mm are used. However, if the Click Rail has to be mounted to a plaster or hollow wall, it is advised to use special plugs. (see assortment accessories).